


Бронзовые гайки, серия TRF



Обозначение	Резьба	d	D	Df	B	L	Dw	dk
TRF-10x2	Tr10x2	8	15	28	4,5	20	21,5	3
TRF-12x3	Tr12x3	9	18	30	5	20	24	3
TRF-12x4	Tr12x4	8	18	30	5	20	24	3
TRF-14x3	Tr14x3	11	20	35	6	25	27,5	4
TRF-14x4	Tr14x4	10	20	35	6	25	27,5	4
TRF-16x4	Tr16x4	12	23	40	6	25	31,6	5